

# NEWS from CPSC

## U.S. Consumer Product Safety Commission

Office of Information and Public Affairs

Washington, DC 20207

FOR IMMEDIATE RELEASE

May 9, 2001

Release # 01-145

**Electric Range Recall Hotline: (800) 462-9267**

CPSC Consumer Hotline: (800) 638-2772

CPSC Media Contact: Scott Wolfson, (301) 504-7051

## CPSC, Maytag Announce Recall of Electric Ranges

WASHINGTON, D.C. - In cooperation with the U.S. Consumer Product Safety Commission (CPSC), **Maytag Corp.**, of Newton, Iowa, is voluntarily recalling about **13,000 Crosley and Magic Chef electric ranges**. Liquid can enter the indicator light and can cause **sparkling and flaming in the light, presenting a fire hazard to consumers**.

Maytag has received **fifteen reports of flames** in the indicator lights. No injuries have been reported.

The recalled electric ranges are 30-inch free-standing units with the control panel in the front between the door panel and main top. The **Crosley brand name ranges have model numbers CE35000AAW or CE35000AAT**, and the **Magic Chef brand name ranges have model numbers CER1110AAT or CER1110AAH**. The brand names can be found on the control panel or the back guard panel and the **model number can be located by opening the storage drawer and looking at the tag on the left side**.

Appliance stores and distributors nationwide sold the ranges from **January 2000 through March 2001** for between \$270 and \$290.

Consumers should stop using their electric ranges immediately and disconnect power to them. Consumers should call Maytag toll-free (800) 462-9267 between 8 a.m. and 5 p.m. ET Monday through Friday for a free in-home repair or log on to the company's website at [www.maytag.com](http://www.maytag.com) to schedule the repair.

